# Scantech ID Scan Kiosk SK-40 SK-50



**Installation Manual** 

Scantech-ID ScanKiosk SK-40 / SK-50

#### Copyright © 2024, Scantech-ID BV.

This manual is copyrighted, with all rights reserved. Under the copyright laws, this manual may not, in whole or in part, be copied, photocopied, reproduced, translated or converted to any electronic medium or machine readable form without prior written consent of ScantechID BV.

#### Limited Warranty

Under all circumstances this manual should be read attentively, before installing and/or using the product. In no event shall Scantech-ID BV be liable for any direct, indirect, special, consequential or incidental damages arising out of the use or inability to use this documentation or product, even if advised of the possibility of such damages. In particular, Scantech-ID BV shall not be liable for any hardware, software, or data that is stored or used with the product, including the cost of repairing, replacing or recovering the above. Scantech-ID BV reserves the right to change parts of the device at any time without preceding or direct announcement to the client.

ScantechID BV reserves the right to revise this manual, and to make changes in the contents without obligation to notify any person or entity of the revision or change. A serial number appears on the product. Make sure that this official registration number has not been removed. It should be used whenever servicing by ScantechID BV or an authorized Scantech dealer is necessary.

#### Important

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to EN55022, and with the limits for a class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the user's manual, may cause harmful interference to radio communications. Operation of the equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. Any unauthorised changes or modifications to this equipment could void the user's authority to operate this equipment.

This device is in conformity with the CE standards. Please note that a Scantech CE-marked power supply unit should be used to conform to these standards.

### Radio and television interference

Operation of this equipment in a residential area can cause interference with radio or television reception. This can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:

- Reorientate the receiving antenna
- · Relocate the devices with respect to the receiver
- Move the device away from the receiver

• Plug the device into a different outlet in order to have the device and receiver on different branch circuits If necessary, the user should consult the manufacturer, an authorized Scantech dealer or experienced radio/television technician for additional suggestions. The booklet "How to Identify and Resolve Radio-TV Interference Problems", prepared by the Federal Communications Commission, can be of help. It can be obtained from the U.S. Government Printing Office, Washington, DC 20402, Stock No. 004000003454.

Due to Scantech's continuing product improvement programs, product features, the information and specifications in this manual are subject to change without prior notice.

# Table of contents

anual		3
nd Safet	y Information	4
Product	t Overview	7
1.1	Introduction	8
1.2	General Product Features	9
1.3	Unpacking	11
1.4	Device Parts	12
1.4.1	Front View	12
1.4.2	Back View	14
1.4.3	Data I/O Compartment	15
1.5	Scanning with the SK-40 / SK-50	16
1.6	Adjusting the scanner angle	18
Installat	ion	21
2.1	Mounting the device	22
2.1.1	VESA Mount	22
2.1.2	Wall Mount	24
2.2	Expanding the memory	26
2.2.1	Installing an SD Card	26
2.2.2	Installing a Flash USB Drive	26
2.3	Connecting the SK-40 / SK50	27
2.3.1	Connect to the local Network	27
2.3.2	Connect peripherals through USB	28
2.3.3	Connect headphone (SK-50)	28
2.3.4	Connect peripherals through RS-232 (SK-50)	29
2.3.5	Connect the Power	29
2.4	Power over Ethernet	30
Maintenance and Cleaning		32
Technical Specifications		33
	nd Safet Produc: 1.1 1.2 1.3 1.4 1.4.1 1.4.2 1.4.3 1.5 1.6 Installat 2.1 2.1.1 2.1.2 2.2 2.2.1 2.2.2 2.3 2.3.1 2.3.2 2.3.3 2.3.4 2.3.5 2.4 Mainten	1.2General Product Features.1.3Unpacking.1.4Device Parts1.4.1Front View.1.4.2Back View1.4.3Data I/O Compartment.1.5Scanning with the SK-40 / SK-501.6Adjusting the scanner angleInstallation.2.1Mounting the device.2.1.1VESA Mount2.2Expanding the memory2.2.1Installing an SD Card2.2.2Installing a Flash USB Drive2.3Connect to the local Network.2.3.2Connect peripherals through USB.2.3.3Connect peripherals through USB.2.3.4Connect the Power2.4Power over EthernetMaintenance and Cleaning

# About this Manual

This manual provides information for installing and operating the Scantech-ID ScanKiosk SK-40/SK-50. Read this manual before operating the device and keep it in a safe place for future reference.

The complete set of SK-40 SK-50 User Documentation consists of:

- This Installation Manual
- The Configuration Manual
- The Integration Manual

At later stage these three documents will be merged into one Reference Bookwork.

## **CHAPTER DESCRIPTIONS**

- Chapter 1: Product Overview introduces the SK-40 / SK-50, and describes its features and unpacking procedures.
- Chapter 2: Installation describes mounting procedures and connecting devices to the SK-40 / SK-50.
- Appendix A: Technical Specifications provides technical information about the SK-40 / SK-50.

## **USED CONVENTIONS**

This manual contains the following conventions:

### NOTE

Gives a tip, an instruction or a point of attention.

### IMPORTANT

Warns for possible damage to the device or other objects when the instruction is not followed.

### DANGER!

Warns for possible harm to persons when the instruction is not followed.

## LASER SAFETY

### IMPORTANT

During installing, always follow the instructions.

### **DANGER!**

Avoid long term viewing of direct laser light. This product is in conformity with IEC 825 Class 1 and 21CFR1040 Class IIa.

#### German:

Der SK-40/50 entspricht den Sicherheitsvorschriften nach IEC 825-1 (1993) für ein Laserprodukt der Klasse I. Er entspricht auch U.S. 21CFR1040, anwendbar auf ein Laserprodukt der Klasse IIa. Vermeiden Sie langzeitiges Hineinblicken in direktes Laserlicht.

#### Dutch:

De SK-40/50 voldoet aan de veiligheidsnormen IEC 825-1 (1993) voor een Klasse I laserproduct. Tevens voldoet de SK-40/50 aan U.S. 21CFR1040, van toepassing op een Klasse IIa laserproduct. Vermijd langdurig kijken in direct laserlicht.

#### French:

Le SK-40/50 est conforme aux normes de sécurité IEC 825-1 (1993) s'appliquant à un produit laser de la classel. Il est également conforme à la U.S. 21CFR1040 telle qu'elle s'applique à un produit laser de la classe Ila. Eviter de rester exposé longtemps à la lumière directe du laser.

#### Danish:

SK-40/50 er i overensstemmelse med sikkerhedsstandarden IEC 825-1 (1993) for laserprodukter i klasse I. Den er også i overensstemmelse med U.S. 21CFR1040, der gælder for laserprodukter i klasse IIa. Undgå at se direkte på laserlys i længere perioder.

### Finnish:

SK-40/50 täyttää luokan I lasertuotteelle IEC 825-1:ssä (1993) asetetut turvavaatimukset. Se täyttää myös U.S. 21CFR1040:ssa asetetut vaatimukset siltä osin kuin ne koskevat luokan Ila lasertuotetta. Vältä pitkäaikaista suoraan laservaloon katsomista.

#### Swedish:

Avsökaren SK-40/50 uppfyller säkerhetsnormen IEC 825-1 (1993) för laserprodukter av klass . Den uppfyller dessutom U.S. 21CFR1040 som gäller för laserprodukter av klass lla. Undvik att titta I direkt laserljus under längre perioder.

### Norwegian:

SK-40/ $\overline{5}$ 0 er i samsvar med sikkerhetsstandarden IEC 825-1 (1993) for laserprodukter i klasse I. Den er også i samvar med U.S. 21CFR1040 for laserprodukter i klasse Ila. Unngå å se langvarig på direkte laserlys.

#### Italian:

Lo SK-40/50 è conforme alle norme di sicurezza IEC 8251 (1993) relative ad un prodotto laser di Classe 1. È inoltre conforme alla norma U.S. 21CFR1040 relativa ad un prodotto laser di Classe IIa. Evitare l'esposizione prolungata all'emissione diretta di luce laser.

### Portuguese:

O SK-40/50 está conforme as normas de segurança IEC 825-1 (1993) para a Classe 1 dos produtos laser. Também está conforme a norma U.S. 21CFR1040 aplicada nos produtos laser da Classe lla. Evite expor os olhos directa e prolongadamente aos raios laser.

#### Spanish:

El SK-40/50 reune las normas de seguridad IEC 825-1 (1993) para un producto laser de Clase 1. Y también reune las normas U.S. 21CFR1040 que se aplican a un producto laser de Clase lla. Se debe evitar mirar muy fijo en luz lasérica directa.

#### English:

The SK-40/50 complies with safety standard IEC 825-1 (1993) for a Class I laser product. It also complies with U.S. 21CFR1040 as applicable to a Class II alser product. Avoid long term viewing of direct laser light.

#### **Optical:**

The use of optical instruments with this product will increase eye hazard. Optical instruments include binoculars, microscopes and magnifying glasses but do not include eyeglasses worn by the user.

#### **Radiant Energy:**

The SK-40/50-Omni uses a low-power laser diode operating at 630...670 nm in an opto-mechanical scanner resulting in less than 0.6 mW peak output power. Laser light observed at 13 cm (5.1 in.) above the window through a 7 mm (0.28 in.) aperture and averaged over 1000 seconds is less than

 $3.9~\mu\text{W}$  per CDRH Class lla specification. Do not attempt to remove the protective housing of the scanner, as unscanned laser light with a peak output up to 0.8 mW could be accessible inside.

#### Laser Light Viewer:

The scanner window is the only aperture through which laser light may be observed on this product. A failure of the scanner motor, while the laser diode continues to emit a laser beam, may cause emission levels to exceed those for safe operation. The scanner has safeguards to prevent this occurrence. If, however, a stationary laser beam is emitted, the failing scanner should be disconnected from its power source immediately.

#### Adjustments:

Do not attempt any adjustments to or alteration of this product. Do not remove the scanner's protective housing. There are no user-serviceable parts inside.

### CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous laser light exposure.

### CAUTION

Risk of Explosion if Battery is replaced by an incorrect Type. Dispose of Used Batteries According to the regular Instructions

# **DECLARATION OF CONFORMITY**

CE

The SK-40 and SK-50 comply with the following product specifications:

Laser safety: IEC825 Class 1 and CDRH 21 CFR 1040

Electrical safety: UL 60950-1 EN 60950-1:2006+A11:2009+A1:2010+A12:2011

 EMC: As set out in the Council Directive of the Laws of the Member States relating to Electromagnetic Compatibility (2004/108/EC) and (2006/95/EC) for the evaluation regarding electromagnetic compatibility. Applicable Standards:
 EN 55022 CLASS B:2006 EN 55024:2001
 EN 61000-3-2:2006+A1:2009+A2:2009 IEC 61000-4-2:2008
 EN 61000-3-3:2008 IEC 61000-4-3:2006+A1:2007+A2:2010 IEC 61000-4-3:2006+A1:2010
 IEC 61000-4-5:2005 IEC 61000-4-6:2008

RoHS2

We hereby certify the above listed products, parts,materials and packaging are in compliance with the European Economic Union (EEU) "Reduction of Hazardous Substances" (RoHS2) Directive 2011 /65/EU, except for the exemptions listed under RoHS2.

IEC 61000-4-8:2009 IEC 61000-4-11:2004

hail we

QA Director January 23 2013

## **SERVICE INFORMATION**

If you might encounter any problem with the product, contact Scantech-ID customer-support in your region, specifying the following information:

- Model and Part number
- Serial number
- The Firmware level as shown on the display after power-up.

# Chapter 1 Product Overview

## 1.1 INTRODUCTION

The SK-40 / SK-50 is a powerful Scan Kiosk that combines the conventional Price Checker with the functionality of a 2D imager or omni-directional laser scanner topped with multimedia capabilities supporting audio and video streaming.

The SK-40 / SK-50 features the latest technology. Interfacing is done either through wired Ethernet or Wireless RF. The big full color display can be used to play slideshows or product promotion videos.

Because of its size and the compact design, the SK-40 / SK-50 can be mounted anywhere in a store. This flexibility of installation is enhanced by the optional WiFi connection or Power-over-Ethernet.

### **General Information**

The Scan Kiosk SK-40 and SK-50 are the latest products developed by Scantech-ID, the company which has more than 15 years of experience in the field of Customer Information Terminals .

## **Quality and Durability**

The SK-40 / SK-50 comes with the same top quality as all other Scantech-ID products. With SK-40 / SK-50, you get the same quality and performance of more expensive products but at a very competitive price. Due to the high MTBF times of every component a long and service free operation time is ensured.

### Flexibility

With its dual mounting options, the SK-40 / SK-50 can be easily installed using the 2 screws or VESA 75mm bracket mounting featured by 4 inserts. The touch screen display (SK-50) and high quality stereo audio make it easy to read prices and product information or playback promotional music and videos.

### Integration

The SK-40 / SK-50 comes with a Web-based Configuration and Management tool for easy setting and single/multi SK-40/50 management. Scantech supplies software sample source code (HTML and more) to get the SK-40/50 easily connected to the (Store's) Database. The protocol specification for easy integration is available at Scantech-ID.

## **1.2 GENERAL PRODUCT FEATURES**

Self-service SCAN KIOSK with touch screen and media display function (SK-50) Color-screen Price Verifier (SK-40)

Multimedia support with High Quality speakers and headphone jack support

Compact dimension for easy to deploy virtually anywhere in the store

Easy to deploy and map out digital promotion image/video media

The rotatable scanner can be tilted upward and downward within a  $30^{\circ}$  range for the best user convenience.

Omni Directional Laser Scanner and 2D Imager available

Networking options: IEEE 802.11 B/G/N 2.4 GHz and Power over Ethernet support

Compliant with VESA 75mm standard mounting or wall mount with 2 screws

Built-in Web Server for user friendly access to remotely configure, diagnosis, monitor and troubleshoot devices

Developer SDK Software Suite support with example Source Code

Entry/Exit-Gate control function support (option)

Expandable — can easily build on by adding third-party USB/RS232 peripherals, including printers, magnetic stripe readers, keyboards and more.



## 1.3 UNPACKING

1. Remove the device from the box and inspect it for damage.

2. Remove other items from the box and check if all accessories are complete. The following items should be present:

- Power adapter
- Installation Manual
- Configuration Manual

3. Keep the packaging material in a safe place. The packaging box may needed when the device needs to be transported at later stage.

### NOTE

If anything is missing or appears damaged, please contact your dealer immediately.

## 1.4 DEVICE PARTS

## 1.4.1 Front View



ltem		Description
1	Touch screen (SK-50)	Displays product information on the 5.7" full- color screen ideal for multimedia applications
1	Display screen (SK-40)	Displays product and price information on the 4.3" full-color screen
2	Speakers	High Quality speakers for superior audio experience
3	Bar Code Scanner	To identify articles by scanning barcodes with the Omni Directional Laser Scanner or 2D Imager
4	Side compartment	<ul> <li>Depending on model and specifications, contains either of the following optional components:</li> <li>Two USB ports: Use for Wi-Fi stick or flash USB drives</li> <li>Power-over-Ethernet module: Use to power the device through powered Ethernet connection (IEEE 802.3af).</li> </ul>
5	SD card compartment	Contains the optional SD card
6	Data I/O compartment	See table on the next page.

To access the side compartment, you need to remove the side compartment cover. Remove the screw to detach the side compartment cover.



## 1.4.2 Back View

All Data I/O connectors are protected by the back compartment cover. Before making any connections, remove the back compartment cover. Press the tab then pull back to detach the back compartment cover.



Figure 3: Back View

## NOTE

The connectors may vary depending on the device model. Some connectors shown above may not be on your device.

## 1.4.3 DATA I/O Compartment

	ltem	Description
1	SD card compartment	Contains the SD card slot
2	Wall mount slots	Used to mount the device on the wall by using two screws
3	LAN port	Connects the device to the network using an Ethernet (RJ-45) cable
4	USB port	Connects USB devices such as a handheld scanner or a flash USB drive The SK-40 has one USB port only in this location
5	Power jack	Connects the power adapter
6	General Purpose Input/Output (GPIO) connector	Entry/Exit-Gate control support NOTE: Available in SK-50.
7	RS-232 connector	Connects an RS-232 handheld scanner or other accessories using an RJ-11 or RJ-14 cable. NOTE: Available in SK-50.
8	Audio phone jack	Connects to a headphone NOTE: Available in SK-50
9	Scanner window lock	Press and hold to adjust the scanner angle

## 1.5 SCANNING WITH SK-40 / SK-50

To scan barcodes, move the barcode towards the scanner window. The device beeps to indicate a successful scan.





## 1.6 ADJUSTING THE SCANNER ANGLE

For the best user convenience, the scanner can be adjusted over a  $30^{\circ}$  angle and locked with steps of  $5^{\circ}$ .

To adjust the tilt:

- 1. Open the back compartment cover.
- 2. Press and hold the scanner window lock and adjust the scanner to desired tilt.



- 3. Release the lock to secure the scanner in place.
- 4. Close the back compartment cover.

## Scanner Angle and Envelope

Product profile showing the scan area at the two extreme scanner positions.





## CHAPTER 2 INSTALLATION

## 2.1 MOUNTING THE DEVICE

Before mounting the device, consider the following to ensure proper mounting and the safety of installation:

- Wall is thick enough to sustain the mounted device
- The mounted height should be convenient enough for everybody to easily scan the article and to comfortably read the display. The recommended height is: 130-150 cm.

The SK-40 / SK-50 provides two mounting options:

- VESA mounting
- Wall mount with 2 screws, compatible with the Scantech-ID SG-15

## 2.1.1 VESA Mounting

Use a VESA 75mm bracket with the 4 x M4 inserts provided in/at the back, the maximum depth is 8mm.





### 2.1.2 Wall Mount with 2 screws

- 1. Select a suitable location to mount the device.
- 2. See the next page for a Drilling Template, mark the location for the mounting screws and drill two holes in the wall.
- 3. Plug the wall-plugs into the holes.
- 4. Screw the mounting screws into the wall.
- 5. Connect the power adapter, cables and other accessories to the device. See the following pages for connection instructions.
- 6. Position the device so the screws fit into the mounting holes and then push the device first to the right and then down to secure it in the right place.





### SK-40 SK-50 Wall Mount Drilling Template:

Enlarge this page to the real product sizes.

Make sure the scaling reference of 100 mm is respected.

## 2.2 EXPANDING THE MEMORY

The SK-40 and SK-50 have standard a built-in flash memory of 256 MB. The flash memory is non-volatile and contains the system firmware, user applications, data, promotion and media files. If necessary the flash memory can be expended in two ways: use an SD card or a USB flash drive.

## 2.2.1 Installing an SD Card

1. Remove the screw securing the SD card compartment cover.



- 2. Insert the SD card.
- 3. Attach the screw back to close the SD card compartment cover.



**2.2.2** Insert a Flash USB Drive into any of the available USB ports in the Data I/O compartment or in the side compartment

## 2.3 CONNECTING THE SK-40 SK-50

Remove the back cover from the I/O compartment. Ref Chapter 1.4.2

## 2.3.1 CONNECT TO THE LOCAL NETWORK

## **Wired Ethernet**

Connect the Ethernet cable into the LAN port in the Data I/O compartment to obtain network access. Apply the (6) cable strain relief pins.



### NOTE

The LAN port contains two network LED indicators.

## **Wireless connection**

A Wi-Fi stick must be present in one of the USB ports in the side compartment or in the Data I/O compartment for wireless connection. The SK-40/50 WiFi version is supplied from the factory with the WiFi USB stick built-in. If placed afterwards: this must a Scantech validated type to guarantee correct wireless communication.

## 2.3.2 Connect peripherals through USB (if applicable)

Connect peripheral devices such as a handheld scanner or Wi-Fi stick to the USB port on the back of the device or in the side compartment.

## NOTE

The number of USB ports may vary depending on model.



## 2.3.3 Connect headphone (if applicable) (SK-50)

Connect the headphone to the audio port on the back of the device. Apply the (6) cable strain relief pins.



## 2.3.4 Connect peripherals through RS-232 (if applicable) (SK-50)

To connect other accessories, such as a handheld scanner, connect the RJ-11/14  $\,$  6pin connector to the RS-232 port on the back of the device. Apply the (6) cable strain relief pins.



## 2.3.5 Connect the Power

Connect the power adapter to the power jack on the back of the device. Apply the (6) cable strain relief pins



## 2.4 POWER OVER ETHERNET

The exceptional low power consumption of SK series enables us to offer the ScanKiosks Powered-over-Ethernet (POE). This is the alternative for powering the SK-40/50 through an external PSU adapter. In this way the device gets its DC power directly from the powered (IEEE 802.3af compliant) Ethernet. There is no need to install a (230/110VAC) mains socket in the middle of the store. This SK-40/50 feature reduces the total installation costs.

This SK-40/50-POE version complies with the official standard: IEEE 802.3af.

The standard CAT5 network cable (8 pin, fully wired) can be used, with the regular maximum length of 100 meter.

Towards the host-side this means that a hub/router is required, supporting the Power-Over-Ethernet (PoE) feature, complying with the official standard for this: IEEE 802.3af. To avoid any mis-communication in this area: Scantech does not supply network components like power injectors, network cabling or powered hubs.

NOTE POE is an optional feature

# Chapter 3 Maintaining the SK-40 SK-50

### CLEANING

The SK-40 SK-50 requires little maintenance. Only occasional cleaning of the display window is necessary to remove dirt and fingerprints. Cleaning can be performed during operation with a non-abrasive glass spray cleaner and a soft lint-free cloth.

Clean the cover and window of the SK-40 SK-50 every now and then. Take care of the following:

- Use a mild glass spray cleaner;
- Spray the cleaner on a soft, lint-free cloth;
- Wipe the SK-40 SK-50 clean.

### IMPORTANT

The exterior of the SK-40 SK-50 should NOT be cleaned with cleaners containing:

- Aromatic hydrocarbons
- Chloride
- Acids, oxidizing agents
- Abrasives
- Other aggressive cleaners

# Appendix A. Technical Specifications SK-40 SK-50

	SK-50	SK-40		
System Architecture				
Processor	Super RISC Processor 400MHz			
Operating Platform	Standard Linux 2.6 Kernel or WinCE 6.0			
Memory Flash	256 MB, expandable with USB flash drive and SD card			
Memory RAM	128 MB			
Output Media				
Display Size	5.7" diagonal	4.3" diagonal		
Brightness	400 nits	350 nits		
Resolution	640 x 480 pixels (65.535 colours)	480 x 272 pixels (65.535 colours)		
Touch Screen	Resistive type	n.a.		
Graphics Supported	PNG, JPEG, GIF, BMP			
Audio Supported	WAV, WMA, MP3			
Video Supported	MPEG-4, H.264			
Audio Ports	High Definition Stereo (16-bit PCM 44.1 KHz)			
Loudspeakers	High Quality loudspeakers for superior audio performance			
Headphone	3.5 mm standard jack	n.a.		
Data Ports				
SD Card Slot	x 1	x 1		
USB 2.0	x 2 (back compartment) x 2 (side compartment)	x 1 (back compartment) x 2 (side compartment)		
LAN port 10/100 MB	x 1	x 1		
Audio port	x 1 (Option)	n.a.		
RS-232 port	x 1 (+5V DC Power)	n.a.		
Power Over Ethernet Module	Optional	Optional		
Entry/Exit Gate Control Function GPIO	Optional (2-pin conn)	n.a.		

Network Interface		
Wired LAN	<ul> <li>Ethernet: 100MB Base-TX/10MB Base-T (802.3) standard on board</li> <li>Power over Ethernet IEEE 802.af optional</li> <li>Two network LED indicators in the LAN connector</li> </ul>	
Wireless LAN	Ex-factory through Wi-Fi module WiFi IEEE 802.11 ac a/b/g/n Supporting dual band 2.4 and 5 GHz frequency	
Encryption Protocols	WPA, PSK and WPA Enterprise security	
Data Input		
Scanner Possibilities	<ul> <li>Omni Directional Laser Scanner:</li> <li>High Speed, hi sensitive and omni-directional scanning.</li> <li>Reading of fragmented bar codes.</li> <li>Visible laser diode 635 nm.</li> <li>Scan pattern: 6 direction scan field, 24 lines.</li> <li>Scan rate: 2000 scans/sec</li> <li>Up to 300 mm @ UPC/EAN 100%, PCS 90% or:</li> <li>2D Imager :</li> <li>Visible light 650nm</li> <li>Scan rate: 200scans/sec auto adaptive in linear mode,</li> <li>56 images/sec auto adaptive 2D mode.</li> <li>Resolution: 752 Hor. X 480 Vert. pixels, 256 gray levels.</li> </ul>	
Symbologies Supported	<ul> <li>Omni Directional Laser Scanner: EAN/UPC/JAN + Add-on, ISBN, Code 128, EAN 128, Code 93, Code 39, Code 32, Codabar, Interleaved 2 of 5, MSI-Plessey and GS1 DataBar.</li> <li>2D Imager: 1D Symbologies: EAN/UPC, Australian Post, Aztec, BPO, Canada Post, Dutch Post, EAN.UCC Composite, Interleaved 2 of 5, Japan Post, MSI Code, Planet, Plessey Code, Postnet, GS1 Databar, Standard 2 of 5, Telepen, TLC 39 2D Symbologies: Datamatrix, Matrix 2 of 5, Maxi 2 of 5, MicroPDF417, PDF417, Maxicode, QR code</li> </ul>	
Scan Pattern Orientation	The Scanner can be adjusted over an angle of 30° and locked with steps of 5° for the best user convenience.	

+12 VDC ± 10% / 1.5A Nominal: less than 1000mA @ 12VDC		
(standard configuration)		
Physical		
193 x 176 x 85 mm (7.6" x 6.9" x 3.3")		
0.9 kg (2 lb)		
Wall mount with 2 screws (Scantech SG-15 compatible) and VESA 75mm bracket mounting		
Environmental		
0° ~ 40°C (32° ~ 104°F)		
-20° ~ 60°C (-4° ~ 140°F)		
5% ~ 95% RH (non-condensing)		
Electrical Safety: CE EN 60950-1 Laser Safety: CDRH 21 CFR part 1040 IEC825 Class 1 IEC60825 Class 1 EMC/BMI/RFI: 2004/108/EC and 2006/95/EC		



ScantechID BV Heliumweg 34 A 3812 RE Amersfoort The Netherlands

+31 (0)33 469 84 00
+31 (0)33 465 06 15
info@scantech-id.com
www.Scantech-ID.com
www.Champtek.com